




Service Part List_CS1800_Version A

No.	Product Model#	Part Number	Description	Qty
1	CS1800	3130408001	Sheath	1
2	CS1800	5620731001	Cross Recessed Pan Head	1
3	CS1800	3521187001	Adjusting Base	1
4	CS1800	5620479001	Screw	40
5	CS1800	2826918001	Cover Assembly	1
6	CS1800	3127504002	Front Handle	1
7	CS1800	3130337001	Rubber Gasket	1
8	CS1800	3660427002	Spring	2
9	CS1800	3422529001	Sprocket	1.0
10	CS1800	5660208002	Gasket	1
11	CS1800	5660242001	"E" Ring	1
12	CS1800	2826745002	Cover ASSY	1
13	CS1800	3706993002	Guide Plate	1
14	CS1800	3810738002	Chain	1
201	CS1800	2826782002	Pump ASSY	1

